Product Size Charts

CHAINSAW Boot Sizes

When choosing your new boots ensure that you have the right size and remember that it is possible to customise the fit of a boot that is slightly too large by adding socks, but it is virtually impossible to do anything about a boot that is too small. If in doubt go for a size that is slightly larger rather than one that is too small. Properly lace up the boot, your toes should not be pushing against the front of the boots. Equally, there should not be as much of a finger width at the heel otherwise your boot is too large for you. We strongly recommend you visit your local dealership when buying new boots so you can try them on to gauge the correct size. One brand sizing may differ slightly to another brand!

Remember once boots have been worn they cannot be returned if you purchased the incorrect size.

EURO	UK	USA
41	7	8
42	8	8.5
43	9	9.5
44	10	10
45	10.5	11
46	11	10.5
47	12	12.5

Understand the washing symbols:



Excessively high washing temperatures or drying of the clothing in an electric dryer will reduce the protective functionality and the wearing properties of a garment. Therefore it is important that you fully understand washing symbols and instructions to individual garments.



Normal wash at 40 degrees C



Do Not Iron



Do Not Tumble Dry



Do Not Dry Clean



Do Not Bleach With Chlorine



Drip Dry Only

KRIEGER SENTINEL & GUARDIAN Chainsaw Trousers						
	XS (20)	S (30)	M (40)	L (50)	XL (60)	XXL (70)
Waist (cm)	67 - 81	75 -89	83 - 97	91 - 105	99 - 113	107 - 121
Waist (in)	26 - 32	29 - 35	32 - 38	36 - 41	39 - 44	42 - 47
Inside Leg (cm)	80	80	80	82	82	82
Inside Leg (in)	31.5	31.5	31.5	32	32	32
Long Leg Version	XS (25)	S (35)	M (45)	L (55)	XL (65)	XXL (75)
Inside Leg (cm)	85	85	85	87	87	87
Inside Leg (in)	33.5	33.5	33.5	34	34	34

When selecting the correct size of trouser the lower figure is based on the waist being relaxed whereas the higher figure is based on the waist being fully stretched. Please allow for freedom of movement when selecting the correct trouser size. Trousers should always be worn with a belt or braces ensuring the trousers are worn correctly.

X25 Hi-Viz T-Shirts						
Short Sleeve	XS (20)	S (30)	M (40)	L (50)	XL (60)	XXL (70)
Chest cm)		98	106	114	119	124
Chest (in)		38.5	41.5	44.5	46.5	48.5
Long Sleeve						
Chest (cm)		104	109	114	119	124
Chest (in)		41	42.5	44.5	46.5	48.5

Many types of hi-viz shirts claim to conform to CE standards but have never been fully certified to the standards. The X25 ventout is fully CE certified in the UK by SATRA and packaged with a Certificate of Conformity.

KRIEGER PRO Work Shirt						
Short Sleeve	XS (20)	S (30)	M (40)	L (50)	XL (60)	XXL (70)
Chest cm)	85	90	95	100	105	110
Chest (in)	33.5	35.5	37.5	39	41	43
Long Sleeve						
Chest (cm)	85	90	95	100	105	110
Chest (in)	33.5	35.5	37.5	39	41	43

EVO-X25 & EVOLUTION 3 Jacket							
Short Sleeve	XS (20) S (30) M (40) L (50) XL (60) XXL (70)						
Chest cm)		92 - 98	99 - 106	107 - 113	114 - 121	122 - 127	
Chest (in)		36 - 38	39 - 41	42 - 44	45 - 47	48 - 50	

This product is not sold or intended as a 100% waterproof garment but does offer the wearer limited protection against showers with its water resistant elements. Full details are published on our website.

EVOLUTION X25 Over Trousers							
	XS (20) S (30) M (40) L (50) XL (60) XXL (70)						
Waist (cm)		74 - 86	80 - 92	86 - 98	92 - 104	98 - 110	
Waist (in)		29 - 33	31 - 36	34 - 38	36 - 41	38 - 44	
Inside Leg (cm)		80	80	80	80	80	
Inside Leg (in)		31	31	31	31	31	

This product is not sold or intended as a 100% waterproof garment but does offer the wearer limited protection against showers with its water resistant elements. Full details are published on our website.

Chainsaw Protective Gloves							
	8 (30)	9 (40)	10 (50)				
To Fit Hand Circumference mm	203	229	254				
Hand Length (Fingertip to wrist excluding cuff) mm	182	192	204				

Cut protection clothing requires special care and should be cleaned regularly. Contamination of clothing (by, for example, tree resins, oil or fuel residues) can have a negative effect on the functionality of the cut protection. The number of times the clothing is cleaned or washed can also (due to the mechanical effects of a washing machine) reduce the effectiveness of the cut protection within the clothing. In order to ensure the best possible protection from a product, the User Instructions for cleaning and care should always be observed.

- . ALWAYS READ THE USER NOTICE FIRST
- . With a hand brush remove excessive dirt and saw dust
- 3. Turn all the pockets inside out to remove any saw dust, then fasten the pocket zippers
- 4. Fasten the fly zipper & button
- 5. Place the trousers in a conventional washing machine at 40 degrees Celsius
- ${\small 6.} \hspace{0.5cm} \textbf{Use conventional household detergent but NEVER use fabric softener}. \\$
- Once washed, turn the trousers inside out and pull the cut protective clothing into shape whilst still damp
- 8. Air Dry only DO NOT place in a Tumble Dryer.
- 9. Once dry check the trousers for any damage (snags or cuts). Repair as necessary according to the manufacturers' instructions

